

SENSZIO

Est. 89

GARMENT MEASURING GUIDE

MEN



GARMENT MEASUREMENTS



JACKET – BACK LENGTH

Put the jacket on the client, mannequin or a hanger, measure from center neck to bottom. Do not include the Collar measurement.



JACKET – SLEEVE LENGTH

Put the jacket on a mannequin or a hanger, measure from shoulder seam to the center of cuff bottom.



JACKET – SHOULDER WIDTH

Put the jacket on a mannequin or hanger or on the client; measure below center neck 4/5inch(2cm) from left shoulder point to right shoulder point.



JACKET – CHEST



Measure from the edge of the jacket to the seam on the back panel. Then measure from that seam to the centre seam. Ensure the chest part is flat without wrinkles, measure below armpit horizontally and straight.



JACKET – WAIST



Measure from the edge of the jacket to the seam on the back panel. Then measure from that seam to the centre seam. Ensure the chest part is flat without wrinkles, measure below armpit horizontally and straight.



JACKET – HIP/SEAT



Measure from the edge of the jacket to the seam on the back panel. Then measure from that seam to the centre seam. Ensure the chest part is flat without wrinkles, measure below armpit horizontally and straight.



JACKET – BICEP

(Can be laid on a flat surface without a mannequin)

Place left hand underneath the sleeve until you hit the armhole. Then measure straight across the sleeve and multiple by 2.



JACKET – CUFF

Make sure the sleeve is flat without wrinkles, measure the inner seam to outer seam at cuff horizontally and multiply by 2.



JACKET – FIRST BUTTON POSITION

Measure from NSP(Neck Shoulder Point) to the center of first buttonhole along lapel.



PANTS - WAIST

Make sure pants is flat without wrinkles, fasten button or zipper, measure the width of waistband and multiply by 2.



PANTS – HIP/SEAT



1/2 Front Hip:

Lay pants flat. Measure straight 1" from the end of the Zipper to the Seam on the right



1/2 Back Hip:

Turn the pants around to the back. Measure straight from the same point on the front and to the centre seam



PANTS – THIGH

Make sure pants is flat without wrinkles, measure horizontally the width 1 inch below the crotch and multiply by 2.



PANTS – KNEE

Fold the pant so the cuff meets the crotch line.
Measure straight horizontally across the folded
line and multiple by 2.



PANTS – LEG BOTTOM

Make sure pants is flat without wrinkles, measure the width of leg bottom and multiply by 2.



PANTS – U-RISE



Measure from center front waistband across crotch to the crotch seam. Then measure from the crotch seam to the center back waistband. center back waistband. Ensure there are no wrinkles.



PANTS – OUTSEAM

Make sure pants is flat without wrinkles, measure from the top of the waistband to the end of the pant cuffs.

